

Machine Cleaning Summary for your GIGA X3 or X8 Water Tank

**Check your machine's maintenance status each day and note the position of the red bars.
A red icon means action is required that day.**

Your Jura machine will provide you with delicious coffee and many years of reliable service, provided you follow the manufacturers recommended maintenance and cleaning schedule. Failure to follow these instructions may result in poor quality coffee, an unreliable machine and expensive engineer call-out fees as cleaning and user issues are not covered by your warranty.

Cleaning the milk system

End of every day - 3 minutes

1. Before starting the Clean Milk System program, please remove the drip tray and drain any contained water away, before reinserting the drip tray back in to the machine.
2. Click the 'P' button and select 'Clean Milk System'.
3. Set the clear plastic Cleaning Tray on drip tray.
4. Squeeze a single dose of milk cleaning granules into larger section of the Cleaning Tray.
5. Connect milk pipe from the spout to the Cleaning Tray.
6. Follow instructions on display.
7. Meanwhile; empty, clean and rinse steel milk pail, steel tube and rubber connector from fridge (if using Cool Control 1L or 2.5L).
8. Empty and rinse the Cleaning Tray after use.

As a reminder the Clean Milk System should be completed daily

Rinsing the drip tray

End of every day - 3 minutes

1. Slide up both spouts and remove drip tray.
2. Dismantle drip tray and rinse parts well under hot water then dry and return to machine. Do not place parts in dishwasher or use chemicals or abrasive sponges for cleaning.
3. Where auto drip waste disposal is fitted, pay particular attention to cleaning the valve at the back of the drip tray as this can block when dirty.
4. Pay particular attention to rinsing the two metal sensors at rear allowing warm water to rinse all over including behind the metal parts.

Machine clean

When 'Clean Machine' icon is red - 20 minutes

1. Click 'P' button and select 'Clean Machine'.
2. Follow instructions on screen including emptying drip tray and grinds container if required.

A Machine Clean is required every 180 drinks, this is shown by the red progress bar in the maintenance menu

Tank Water Filter Change

When filter icon is red - 10 minutes

1. Empty water tank.
2. Lift black flap and remove used filter.
3. Insert new filter, checking position when you close black flap down.
4. Fill tank, replace on machine and allow filter to automatically rinse.
5. Empty drip tray.

Descale

When 'Descale' icon is red - 45 minutes

1. Empty water tank.
2. Remove water filter.
3. Add four descale tablets to tank.
4. Add 800ml of warm water - wait for tablets to dissolve.
5. Click start in maintenance menu.
6. Empty drip tray.

Use only a damp microfibre cloth for cleaning of the outside of your machine. Chemicals can be corrosive and abrasive sponges will scratch and damage.

For more information please contact us:

0330 133 0281
support@amamus.coffee
www.amamus.coffee

