

Cleaning Summary for your GIGA X3c or X8c Mains Water

**Check your machine's maintenance status each day and note the position of the red bars.
A red icon means action is required that day.**

Your Jura machine will provide you with delicious coffee and many years of reliable service, provided you follow the manufacturers recommended maintenance and cleaning schedule. Failure to follow these instructions may result in poor quality coffee, an unreliable machine and expensive engineer call-out fees as cleaning and user issues are not covered by your warranty.

Cleaning the milk system

End of every day - 3 minutes

1. Before starting the Clean Milk System program, please remove the drip tray and drain any contained water away, before reinserting the drip tray back in to the machine.
2. Click the 'P' button and select 'Clean Milk System'.
3. Set the clear plastic Cleaning Tray on drip tray.
4. Squeeze a single dose of milk cleaning granules into larger section of the Cleaning Tray.
5. Connect milk pipe from the spout to the Cleaning Tray (draw the milk pipe out of the milk container in the fridge, through the hole in the fridge door).
6. Follow instructions on display.
7. Meanwhile; empty, clean and rinse the 4L milk container from the Universal Fridge.
8. Empty and rinse the Cleaning Tray after use.

As a reminder the Clean Milk System should be completed daily

Rinsing the drip tray

End of every day - 3 minutes

1. Slide up both spouts and remove drip tray.
2. Dismantle drip tray and rinse parts well under hot water then dry and return to machine. Do not place parts in dishwasher or use chemicals or abrasive sponges for cleaning.
3. Where auto drip waste disposal is fitted, pay particular attention to cleaning the valve at the back of the drip tray as this can block when dirty.
4. Pay particular attention to rinsing the two metal sensors at rear allowing warm water to rinse all over including behind the metal parts.

Descale and filter change

If either of these icons is red within your blue maintenance menu, please contact amamus immediately as urgent action is required.

A Machine Clean is required every 180 drinks, this is shown by the red progress bar in the maintenance menu

Machine clean

When 'Clean Machine' icon is red - 20 minutes

1. Click 'P' button and select 'Clean Machine'.
2. Follow instructions on screen including emptying drip tray and grinds container if required.
3. When prompted to add tablet, lift chrome flap behind rotary wheel and drop into chute on top of machine.

Basic annual service

1. Will be provided by amamus when you have opted for our Maintenance & Care Package.
2. Includes an inspection, replacing some consumable parts, cleaning sensors, water filter change and descale.

Use only a damp microfibre cloth for cleaning of the outside of your machine. Chemicals can be corrosive and abrasive sponges will scratch and damage.

For more information please contact us:

0330 133 0281
support@amamus.coffee
www.amamus.coffee

