Amamus[•]

Machine Cleaning Summary for your JURA JX8

Check your machine's maintenance status each day and note the position of the red bars. A red icon means action is required that day.

Your Jura machine will provide you with delicious coffee and many years of reliable service, provided you follow the manufacturers recommended maintenance and cleaning schedule. Failure to follow these instructions may result in poor quality coffee, an unreliable machine and expensive engineer call-out fees as cleaning and user issues are not covered by your warranty.

Cleaning the milk system End of every day - 3 minutes

1. Click left-hand black button and select 'Clean

Machine clean When 'Clean Machine' icon is red - 20 minutes Descale When 'Descale' icon is red - 45 minutes

- Milk System'.
- 2. Set the clear plastic Cleaning Tray on drip tray.
- **3.** Squeeze a single dose of milk cleaning granules into larger section of the Cleaning Tray.
- **4.** Connect milk pipe from the spout to the Cleaning Tray.
- 5. Follow instructions on display.
- **6.** Meanwhile; empty, clean and rinse steel milk pail, steel tube and rubber connector from fridge.
- 7. Empty and rinse the Cleaning Tray after use.

Rinsing the drip tray End of every day - 3 minutes

- 1. Slide up spout and remove drip tray.
- 2. Dismantle drip tray and rinse parts well under hot water then dry and return to machine. Do not place parts in dishwasher or use chemicals or abrasive sponges for cleaning.
- **3.** Pay particular attention to rinsing the two metal sensors at rear allowing warm water to rinse all over including behind the metal parts.

For more information please contact us:

- **1.** Click left-hand black button which should be highlighted 'Clean Machine'.
- **2.** Follow instructions on screen including emptying drip tray and grinds container.
- **3.** When prompted to add tablet, lift flap and drop into chute on top of machine behind the bean hopper.

Tank Water Filter Change When filter icon is red - 10 minutes

- 1. Empty water tank.
- 2. Lift black flap and remove used filter.
- **3.** Insert new filter, checking position when you close black flap down.
- **4.** Fill tank, replace on machine and allow filter to automatically rinse.
- 5. Empty drip tray.

- **1.** Select 'descale' from your maintenance menu and click start.
- 2. Empty water tank.
- 3. Remove water filter.
- 4. Add three descale tablets to tank.
- **5.** Add 600ml of warm water wait for tablets to dissolve.
- **6.** Click start in maintenance menu and wait to finish.
- 7. Replace filter.
- 8. Empty drip tray.

Use only a damp microfibre cloth for cleaning of the outside of your machine. Chemicals can be corrosive and abrasive sponges will scratch and damage.

0330 133 0281 support@amamus.coffee www.amamus.coffee

